


UPS LED indicator lights



① Power button: On / Off

② **Green** LED: AC input indicator. It illuminates continuously when the grid power is on and turns off when grid input power fails.

③ **Yellow** LED: indicates battery status. It flashes when battery is charging and illuminates continuously when battery is fully charged.

④ **Red** LED: indicates battery output. It illuminates continuously when AC input power fails.